

Installing Your Dimensional Letters

1

Position the template. It's important to **make sure the template is centered and level**. Secure the template with painter's tape.

2

Remove the peel-n-stick backing from the letters. Carefully press them into position using the template as a guide.

3

Remove the template and you're all done.

Questions. Problems.

856-424-2870

And yes, we actually answer our phones.

